


EM1-MkII LEVER & CONTROL WHEELS



EM1-MkII TOP-LEFT (L1)

This section details the functions of the L1 lever and its associated control wheels (W1F and W2R) when the camera is in Aperture Priority mode. Callouts point to specific camera controls:

- W1F:** HDR Exposure & Bracketing options. ???
- W2R:** Shutter Options, + Bursts, Delay, etc.
- W1F:** Metering Options, Average, Spot, etc.
- W2R:** Focus Options, S-AF, C-AF, TR, Manual, etc.

EM1-MkII TOP-LEFT (L2)

This section details the functions of the L2 lever and its associated control wheels (W1F and W2R) when the camera is in Shutter Priority mode. Callouts point to specific camera controls:

- W1F:** Bracketing Options, Exposure, Focus, ISO, Art, etc. ???
- W2R:** ..various Options for Above Settings !
- W1F:** Exposure Compensation.
- W2R:** Flash Options.